152958 39/0en 16-02-2005 10:50 Pagina 1

FAVORIT 64080 VIL

Dishwasher

Instruction book



PERFEKT IN FORM UND FUNKTION

AEG

Electrolux

Dear customer,

Please read this User Information carefully and keep it to refer to at a later date.
Pass it on to any subsequent owner of the appliance.

The following symbols are used in the text:

Safety instructions
Warning! Notes that concern your personal safety.
Attention! Notes that show how to avoid damage to the appliance.

Useful tips and hints

Environmental information

Your dishwasher has the new washing system "IMPULSE WASHING". With this dishwashing system the motor speed and spray pressure are varied during the wash cycle to achieve better cleaning of the dishes. It is for this reason that the noise level varies during the dishwashing cycle.

152958 39/0en 16-02-2005 10:50 Pagina 3

CONTENTS

Operating instructions 4
Safety instructions 4
Disposal 6
Economical and ecological dishwashing 6
Description of the appliance 7
The control panel 8
Prior to using for the first time 12
The water softener 12
Filling with dishwasher salt 15
Rinse aid 16
In daily use 18
Loading cutlery and dishes 18
The lower basket 20
The cutlery basket 21
The upper basket 22
Adjusting the height of the upper basket 23
Use of detergent 24
Different kinds of detergent 25
Washing programmes 27
Starting a washing programme 28
Maintenance and cleaning 31
Cleaning the filters 31
What to do, when... 34
Service 37
Guarantee terms 38
Technical specifications 41
Installation instructions 42
Building-in 42
Levelling 42
Fixing to the adjacent units 42
Water supply connections 43
Water inlet hose with safety valve 44
Water outlet hose connection 45
Electrical connection 46
Hints for test centres 47

152958 39/0en 16-02-2005 10:50 Pagina 4

OPERATING INSTRUCTIONS

⚠ Safety instructions

The safety of AEG electrical appliances conforms to accepted rules of technology and the Appliance Safety Act. We as manufacturers, however, see ourselves as being obliged to familiarise you with the following safety instructions.

It is most important that this instruction book should be retained with the appliance for future reference. Should the appliance be sold or transferred to another owner, or should you move house and leave the appliance, always ensure that the book is left with the appliance in order that the new owner can get to know the functioning of the appliance and the relevant safety information.

This information has been provided in the interest of your safety. You MUST read it carefully before installing or using the appliance.

Installation

- Check your dishwasher for any transport damage. Never connect a damaged machine. If your dishwasher is damaged, you should contact your supplier.
- For safety reasons it is dangerous to alter the specifications or attempt to modify this product in any way.
- Any electrical and plumbing work required to install this appliance should be carried out by a qualified and competent person.
- Care must be taken to ensure that the appliance does not stand on the electrical supply cable.
- The sides of the dishwasher must never be drilled to prevent damage to hydraulic components.

Child safety

- This appliance is designed to be operated by adults.
- Children should not be allowed to tamper with the controls or play with the product.
- Packaging parts may be dangerous for children, who could even be suffocated! You should therefore keep all packaging well away from children.

152958 39/0en 16-02-2005 10:50 Pagina 5

- The water in your dishwasher is not for drinking. Detergent residues may still be present in your machine. Keep children well away from your dishwasher when the door is open.
- Keep all detergents in a safe place out of children's reach.

Your dishwasher in day-to-day use

- Items that are contaminated by petrol, paint, steel or iron debris, corrosive, acidic or alkaline chemicals must not be washed in this dishwasher.
- Under no circumstances should you open the door whilst the appliance is in operation, especially during the washing phase, hot water may escape. However, if the door is opened, a safety device ensures that the machine stops.
- Only use products (detergent, salt and rinse aid) specifically designed for use in dishwashers.
- Long bladed knives stored in an upright position are a potential hazard.
- Long and/or sharp items of cutlery such as carving knives must be positioned horizontally in the upper basket.
- Ensure that the door of the dishwasher is always closed when it is not being loaded or unloaded. In this way you will avoid anybody tripping over the open door and hurting themeselves.
- When finishing loading or unloading close the door, as an open door can be a hazard.
- Do not sit or stand on the open door.
- Isolate the appliance from the power supply and turn off the water supply after use.
- This product should be serviced by an authorised service engineer, and only genuine spare parts should be used.
- Under no circumstances should you attempt to repair the machine yourself. Repairs carried out by inexperienced persons may cause injury or serious malfunctioning. Contact your local Service Force Centre. Always insist on genuine spare parts.

152958 39/0en 16-02-2005 10:50 Pagina 6

Disposal

Dispose of the dishwasher packaging material correctly.
All packaging materials can be recycled.

Plastic parts are marked with standard international abbreviations:

>PE< for polyethylene, e.g. sheet wrapping material.

>PS< for polystyrene, e.g. padding material (always CFC-free).

>POM< for polyoxymethylene, e.g. plastic clips.

Cardboard packaging is manufactured from recycled paper and should be deposited in the waste paper collection for recycling.
As and when you cease to use your dishwasher and withdraw it from service, your should render it unserviceable before having it disposed of.

Warning! Children at play could lock themselves in your dishwasher or otherwise endanger their lives. Therefore cut off the power supply cable and make the door closing device unusable to prevent children from being trapped inside.

For the disposing of the appliance please take it to a recycling centre or to your dealer who may, for a small contribution to the costs, dispose it for you.

The symbol on the product or on its packaging indicates that this product may not be treated as household waste. Instead it shall be handed over to the applicable collection point for the recycling of electrical and electronic equipment. By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling of this product. For more detailed information about recycling of this product, please contact your local city office, your household waste disposal service or the shop where you purchased the product.

Economical and ecological dishwashing

- Ensure that the water softener is correctly adjusted.
- Do not pre-wash under running water.
- Select the wash programme to suit the nature and degree of the soiling on the dishes.
- Do not use more detergent, special salt and rinse aid than is recommended in these operating instructions and by the manufacturer of the respective product.

152958 39/0en 16-02-2005 10:50 Pagina 7

Description of the appliance



1. Upper basket stop
2. Water hardness switch
3. Salt container
4. Detergent dispenser
5. Control panel
6. Rating plate
7. Rinse aid dispenser
8. Filters
9. Lower spray arm
10. Upper spray arm
11. Upper basket

152958 39/0en 16-02-2005 10:50 Pagina 8

The control panel



Function buttons: in addition to the dishwashing programme selected and the "delay start", the following functions can also be set with the help of these buttons:
- the setting of the water softener,
- activation/deactivation of the dosage of rinse aid,
- activation/deactivation of the audible signals,
- the cancelling of a programme in progress.

Programme selection buttons: allows the selection of the desired washing programme (see "Washing programmes" chart).

"Delay start" button: this option allows the start of the programme to be delayed from 1 to 19 hours. The corresponding indicator light illuminates.

The digital display indicates:
- the level of hardness to which the water softener is set,
- if the audible signals are activated/deactivated,
- if the dosage of rinse aid is activated/deactivated,
- the countdown of the delay start,
- the approximative remaining time of the running programme,
- fault codes concerning malfunction of the dishwasher.

152958 39/0en 16-02-2005 10:50 Pagina 9

Indicator lights: have the following meanings:

	Salt refilling indicator light, illuminates when the salt has run out
	Rinse aid refilling indicator light, illuminates when the rinse aid has run out

"3 in 1" button : This appliance is equipped with the **3 in 1 function**, that allows the use of the "3 in 1" combi detergent tablets.
This function can be selected with all washing programmes.
With the selection of this function the inflow of rinse aid and salt from each respective supply container is automatically deactivated and also the indicator lights for salt and rinse aid are deactivated.
Select the **3 in 1 function** before the set of a washing programme.
With the use of the **3 in 1 function**, the cycle durations may change. In this case, in the digital display, the indication of the running time of the programme is automatically updated.
Once selected this function (button indicator light illuminated) it will remain active also for the following washing programmes, to deactivate the function, press the button (button indicator light off).
NOTE: Once the programme is running, the **3 in 1 function** can **NO** longer be changed. If you want to exclude the **3 in 1 function** you have to cancel the programme setting (see chapter "Starting a washing programme" - "To cancel a washing programme in progress") and then deactivate the **3 in 1 function** by pressing the 3 in 1 button.
In this case you have to set a washing programme again.

152958 39/0en 16-02-2005 10:50 Pagina 10

NOTE: if the drying results are not satisfactory it is possible to activate only the dosage of rinse aid.
The activation/deactivation of the dosage of rinse aid can only be possible with the **3 in 1 fuction** active.

Activation/deactivation of the dosage of rinse aid

(The dishwasher must be switched off)

When the dosage of rinse aid has been activated, also the rinse aid indicator light on the control panel is automatically activated.

1. Press the On/Off button. All programme selection buttons indicator lights will illuminate (setting mode).
If only one programme selection button indicator light is illuminated, this means that a washing programme has been set. The programme must be cancelled: press simultaneously the function buttons **2** and 3 for about 2 seconds, the indicator light of the set programme button starts flashing for about 2 seconds. After about 2 seconds the indicator lights of all the programme selection buttons will illuminate indicating that the set programme has been cancelled and that the machine is now in setting mode.

2. Press simultaneously function buttons **2** and **3**, until the indicator lights of the function buttons **1**, **2** and **3** start flashing.

3. Press the function button **2**, the indicator lights of function buttons **1** and **3** turn off while the indicator light of the function button **2** goes on flashing, the digital display indicates the current setting.

0d	**Rinse aid dosage deactivated**
1d	**Rinse aid dosage activated**

4. To change the setting, press the function button **2** again, the digital display indicates the new setting.

5. To memorise the operation, switch off the dishwasher by pressing the On/Off button or wait about 60 seconds after which the dishwasher will automatically return to setting mode.

152958 39/0en 16-02-2005 10:50 Pagina 11

Audible signals

Audible signals have been introduced to help indicate which operations the dishwasher is performing:

- **Setting of the water softener**
- **End of programme**
- **Something not working with the machine**

Deactivation/activation of the audible signals

(The dishwasher must be switched off)

Factory setting: **audible signals activeted**

1. Press the On/Off button. All programme selection buttons indicator lights will illuminate (setting mode).
If only one programme selection button indicator light is illuminated, this means that a washing programme has been set. The programme must be cancelled: press simultaneously the function buttons **2** and **3** for about 2 seconds, the indicator light of the set programme button starts flashing for about 2 seconds. After about 2 seconds the indicator lights of all the programme selection buttons will illuminate indicating that the set programme has been cancelled and that the machine is now in setting mode.

2. Press simultaneously function buttons **2** and **3**, the indicator lights of the function buttons **1**, **2** and **3** start flashing.

3. Press the function button **3**, the indicator lights of function buttons **1** and **2** turn off while the indicator light of the button **3** goes on flashing, the digital display indicates the current setting.

0b	**Audible signals deactivated**
1b	**Audible signals activated** (factory set)

4. To change the current setting, press again the function button **3**, the digital display will indicate the new setting.

5. To memorise the operation, switch off the dishwasher by pressing the On/Off button or wait about 60 seconds after which the dishwasher will automatically return to setting mode.

152958 39/0en 16-02-2005 10:50 Pagina 12

Prior to using for the first time

Before using your dishwasher for the first time:

1. Ensure that the electrical and water connections comply with the installation instructions
2. Remove all packaging from inside the appliance
3. Set the water softener
4. Pour 1 litre of water inside the salt container and then fill with dishwasher salt
5. Fill the rinse aid dispenser.

The water softener

The dishwasher is equipped with a water softener designed to remove minerals and salts from the water supply, which would have a detrimental or adverse effect on the operation of the appliance.

The higher the content of these minerals and salts, the harder your water is.

Water hardness is measured in equivalent scales, German degrees, French degrees and mmol/l (millimol per litre).

The softener should be adjusted according to the hardness of the water in your area. Your local Water Authority can advise you on the hardness of the water in your area.

The water softener must be set in both ways: manually, using the water hardness dial and electronically, using the function buttons on the control panel.

Water hardness				Adjusting the water hardness setting		Level indicated in the digital display	Number of audible signals
°dH (german degrees)	°TH (french degrees)	mmol/l (millimol per litre, international unit for the hardness of water)	Range	Manually	Electronically		
51 - 70	91 - 125	9,0 - 12,5	IV	2	10	10L	10
43 - 50	76 - 90	7,6 - 8,9			9	9L	9
37 - 42	65 - 75	6,5 - 7,5			8	8L	8
29 - 36	51 - 64	5,1 - 6,4			7	7L	7
23 - 28	40 - 50	4,0 - 5,0			6	6L	6
19 - 22	33 - 39	3,3 - 3,9	III		5	5L	5
15 - 18	26 - 32	2,6 - 3,2		1	4	4L	4
11 - 14	19 - 25	1,9 - 2,5	II		3	3L	3
4 - 10	7 - 18	0,7 - 1,8	I/II		2	2L	2
< 4	< 7	< 0,7	I		1 no salt necessary	1L	1

152958 39/0en 16-02-2005 10:50 Pagina 13

a) Setting manually

1. Open the dishwasher door.

2. Remove the lower basket from the dishwasher.

3. Turn the water hardness dial to position 1 or 2 (see table).

4. Replace the lower basket.

The dishwasher is factory set at position 2.



b) Setting electronically

(The dishwasher must be switched off)

NOTE: the electronic setting of the water softener is possible **ONLY** with the **3 in 1 function** deactivated.

The dishwasher is factory set at level 5.

1. Press the On/Off button. All programme selection buttons indicator lights will illuminate (setting mode).
If only one programme selection button indicator light is illuminated, this means that a washing programme has been set. The programme must be cancelled: press simultaneously the function buttons 2 and **3** for about 2 seconds, the indicator light of the set programme button starts flashing for about 2 seconds. After about 2 seconds the indicator lights of all the programme selection buttons will illuminate indicating that the set programme has been cancelled and that the machine is now in setting mode.

2. Press simultaneously function buttons **2** and **3**, until the indicator lights of the function buttons **1**, **2** and **3** start flashing.

152958 39/0en 16-02-2005 10:50 Pagina 14

3. Press the function button **1**, the indicator lights of function buttons 2 and 3 turn off while the indicator light of the button **1** goes on flashing, the digital display indicates the current level and a sequence of intermittent audible signals are heard.
The current level is indicated by the number visible in the display and the number of intermittent audible signals heard.

Example:

5 L displayed + 5 audible signals = level 5.

4. To change the level, press button **1**. Each time the button is pressed the level changes. (For the selection of the new level see the chart).

Examples:

if the current level is 5, by pressing button **1** once, level 6 is selected.

if the current level is 10, by pressing button **1** once, level 1 is selected.

5. To memorise the operation, switch off the dishwasher by pressing the On/Off button or wait about 60 seconds after which the dishwasher will automatically return to setting mode.

152958 39/0en 16-02-2005 10:50 Pagina 15

Filling with dishwasher salt

Only use salt specifically designed for use in dishwashers.
All other types of salt not specifically designed for use in a dishwasher, especially table salt, will damage the water softener.
Only fill with salt just before starting one of the complete washing programmes.
This will prevent any grains of salt or salty water, which may have been spilt, remaining on the bottom of the machine for any period of time, which may cause corrosion.

To fill:

1. Open the door, remove the lower basket and unscrew the cap of the salt container by turning it anticlockwise.

2. Pour 1 litre of water inside the container (this is necessary only before filling with salt for the first time).

3. Using the funnel provided, pour in the salt until the container is full.

4. Replace the cap making sure that there is no trace of salt on the screw thread or on the gasket.

5. Replace on the cap tightly turning it clockwise until it stops with a click.



The salt container will require topping up periodically. You are reminded of this by the salt indicator light on the control panel which comes on when the salt has finished.

The salt indicator light on the control panel can remain illuminated for 2-6 hours after the salt has been replenished, assuming the dishwasher remains switched on. If you are using salts that take longer to dissolve then this can take longer. The function of the machine is not affected.

Do not worry if water over flows from the unit when filling with salt, this is quite normal.

152958 39/0en 16-02-2005 10:50 Pagina 16

Rinse aid

Rinse aid is automatically added during the last rinse, ensuring thorough rinsing, and spot and streak free drying. The dispenser, which is positioned inside the door, holds about 110 ml of rinse aid, which is sufficient for 16 - 40 dishwashing programmes, depending upon the dosage setting.

Filling with rinse aid

1. Open the container by pressing the release button (A).

2. Add the rinse aid until the container is completely full. The maximum level for filling is indicated by “max”.





Ensure that the lid is closed after every refill.

Clean up any rinse aid spilt during filling with an absorbent cloth to avoid excess foaming during the next wash.

Only use branded rinse aid for dishwashers. Never fill the rinse aid dispenser with any other substances (e.g. dishwasher cleaning agent, liquid detergent). This would damage the appliance.

152958 39/0en 16-02-2005 10:50 Pagina 17

Adjusting the dose

According to the finish and drying results obtained, adjust the dose of rinse aid by means of the 6 position selector (position 1 minimum dosage, position 6 maximum dosage).

The dose is factory set in position 4.

Increase the dose if there are drops of water or lime spots on the dishes after washing.

Reduce it if there are sticky whitish streaks on the dishes or a bluish film on glassware or knife blades.



Top up the rinse aid when the indicator light on the control panel illuminates.

152958 39/0en 16-02-2005 10:50 Pagina 18

In daily use

- Check if it's necessary to refill with dishwasher salt or rinse aid.
- Load cutlery and dishes into the dishwasher.
- Fill with dishwasher detergent.
- Select a wash programme suitable for the cutlery and dishes.
- Start the wash programme.

Loading cutlery and dishes

Sponges, household cloths and any object that can absorb water may not be washed in the dishwasher.

- Before loading the dishes, you should:
  - Remove large left-overs.
  - Soften remnants of burnt food in pans.
- When loading the dishes and cutlery, please note:
  - Dishes and cutlery must not impede the rotation of the spray arms.
  - Load hollow items such as cups, glasses, pans etc, with the opening downwards so that water cannot collect in the container or a deep base.
  - Dishes and items of cutlery must not lie inside one another, or cover each other.
  - To avoid damage to glasses, they must not touch.
  - Lay small objects in the cutlery basket.
- **Plastic items and pans with teflon have a tendency to retain water drops; these items will not dry as well as porcelain and steel items.**

152958 39/0en 16-02-2005 10:50 Pagina 19

For washing in the dishwasher the following cutlery/dishes	
are not suitable:	are of limited suitability:
• Cutlery with wooden, horn, china or mother-of-pearl handles • Plastic items that are not heat resistant • Older cutlery with glued parts that is not temperature resistant • Bonded cutlery items or dishes • Pewter or copper items • Lead crystal glass • Steel items subject to rusting • Wooden platters • Items made from synthetic fibres	• Only wash stoneware in the dishwasher if it is specifically marked as being dishwasher-safe by the manufacturer. • Glazed patterns may fade if machine washed frequently. • Silver and aluminium parts have a tendency to discolour during washing. Residues, e.g. egg white, egg yolk and mustard often cause discolouring and staining on silver. Therefore always clean left-overs from silver immediately, if it is not to be washed straight after use. • Some types of glass can become dull after a large number of washes.

152958 39/0en 16-02-2005 10:50 Pagina 20

Open the door and slide out the baskets to load the dishes.

The lower basket

The lower basket is designed to take saucepans, lids, plates, salad bowls, cutlery etc.

Serving dishes and large lids should be arranged around the edge of the basket, ensuring that the spray arms can turn freely.


UI90


UI91

The rows of prongs on the lower basket can be easily lowered to allow you to load pots, pans and bowls.


UI88

152958 39/0en 16-02-2005 10:50 Pagina 21

The cutlery basket

Long bladed knives stored in an upright position are a potential hazard.
Long and/or sharp items of cutlery such as carving knives must be positioned horizontally in the upper basket.
Take care when loading or unloading sharp items such as knives.

Removable knife basket

Long and/or sharp items of cutlery such as carving knives must be placed horizontally in the removable knife basket, which is positioned at the rear of the upper basket.



Forks and spoons should be placed in the removable cutlery basket with the handles facing downwards and the knives with their handles facing upwards.
If the handles protrude from the bottom of the basket, obstructing the lower spray arm, load the cutlery with the handles facing upwards.

Mix spoons with other cutlery to prevent them from sticking together.

For best results we recommend you to use the cutlery grid provided (if the size and dimensions of the cutlery allow it).



152958 39/0en 16-02-2005 10:50 Pagina 22

The upper basket

The upper basket is designed for plates (dessert plates, saucers, dinner plates of up to 26 cm in diameter), salad bowls, cups and glasses.

Arrange items on and underneath the cup racks so that water can reach all surfaces.

For taller items, the cup racks can be folded upwards.

Light items (plastic bowls etc.) must be loaded in the upper basket and arranged so they do not move.


US47


US73

For glasses with long stems (according to the size and dimensions), upset the glass holder to the left-hand or right-hand position.

In case you need to load dishes in the upper basket, the glass holder must be in the right-hand position.


US82


US83

In case that plates are loaded in the upper basket:
load them starting from the rear positions of the basket; tilting them slightly forwards and avoiding the front positions near the door.


US71

Before closing the door, ensure that the spray arms can rotate freely.

Adjusting the height of the upper basket

If washing very large plates you can load them in the lower basket after moving the upper basket to the higher position.

	Maximum height of the dishes in: upper basket	lower basket
With upper basket raised	**22 cm**	**33 cm**
With upper basket lowered	**26 cm**	**29 cm**

To move to the higher position proceed as follows:

1. Pull out the basket until it stops.

2. Carefully lift both sides upwards until the mechanism is engaged and the basket is stable.

Attention!
Never lift or lower the basket on one side only.

When the basket is in the heigher position you will not be able to use the cup rack(s).


RC08

The lower the basket to the original position proceed as follows:

1. Pull out the basket until it stops.

2. Carefully lift both sides upwards and then allow the mechanism to drop back down slowly, keeping hold of it.

After loading your machine always close the door, as an open door can be a hazard.

152958 39/0en 16-02-2005 10:50 Pagina 24

Use of detergent

Only use detergents specifically designed for use in dishwashers.

Using no more then the correct amount of detergent contributes to reducing pollution.

Please observe the manufacturer's dosing and storage recommendations as stated on the detergent packaging.

Fill with detergent

1. If the lid is closed: press release button (1). The lid springs open.

2. Fill the detergent dispenser (2) with detergent.

The marking indicates the dosing levels:

20 = approximately 20 g of detergent

30 = approximately 30 g of detergent





3. All programmes with prewash need an additional detergent dose (5/10 g) that must be placed in the prewash detergent chamber (3). This detergent will take effect during the prewash phase.

4. Close the lid and press until it locks in place.

152958 39/0en 16-02-2005 10:50 Pagina 25

Different kinds of detergent

Detergent tablets

Detergent tablets of different brands dissolve at different speeds. For this reason some detergent tablets cannot dissolve and develop their full cleaning power during short programmes. Therefore please use long programmes when using detergent tablets, to ensure the complete removal of detergent residuals.

Do not place the tablets in the tub or in the cutlery basket as this will result in poorer wash results. The tablets should be placed in the detergent dispenser.

Concentrated detergent

Based on their chemical composition, dishwasher detergents can be split into two basic types:

- conventional, alkaline detergents with caustic components.
- low alkaline concentrated detergents with natural enzymes.

The use of 50°C washing programmes in conjunction with concentrated detergents reduces pollution and is good for your dishes; these wash programmes are specially matched to the dirt-dissolving properties of the enzymes in the concentrated detergent. For this reason 50°C wash programmes in which concentrated detergents are used can achieve the same results that can otherwise only be achieved using 65°C programmes.

Combi detergents

If you are using dishwasher detergent that includes the rinse aid function, this must be placed in the detergent compartment.
In this case the rinse aid dispenser must be empty, in order to avoid a double dosage.
If in the rinse aid dispenser there is still rinse aid you must wait until it has finished before using these kind of detergents.

The rinse aid indicator light will always remain illuminated when the machine is switched on (not all dishwasher models are foreseen with rinse aid indicator light).

Special salt for dishwasher **must** still be used.

152958 39/0en 16-02-2005 10:50 Pagina 26

Use of "3 in 1" combi detergents

General advice

These products are detergents with integrated and combined detergent/rinse-aid and salt functions.

1. **Before using these products you should first check that the water hardness in your supply is compatible with the use of these products as per the detergent manufacturers (on the product packaging).**
2. These products should be strictly used according to the detergent manufacturers instructions.
3. If you encounter problems when using 3 in 1 products for the first time then please contact the detergent manufacturers care line (the telephone number is given on the product packaging).

Special advice

When using combination 3 in 1 products, we recommend the use of the “3 in 1” function.

If you decide to turn back to the use of the standard detergent system we advise that you:

- Refill both the salt container and rinse aid dispenser.
- Switch the water hardness setting to the highest possible position and run from 1 to 3 normal washing programmes without a load.
- Readjust the water hardness setting again according to the hardness of the water in your area.

152958 39/0en 16-02-2005 10:50 Pagina 27

Washing programmes

Programme	Type of load	Degree of soil	Cycle description					Consumption values[3]		
			Pre-rinse	Main wash	Intermediate	Final rinse	Drying	Duration (minutes)	Energy (kWh)	Water (litres)
AUTOMATIC	Crockery and cutlery	Normal soil	•	•	• 1/2x	•	•	92 - 115	1,1 - 1,5	12 - 25
30 MIN [1]	Crockery and cutlery	Fresh soil	-	•	-	•	-	30	0,8	9
INTENSIVE CARE 70°	Crockery, cutlery, pots and pans	Heavy soil	•	•	• 2x	•	•	120 - 130	1,7 - 1,9	23 - 25
ECO 50° [2]	Crockery and cutlery	Normal soil	•	•	•	•	•	155 - 165	0,95 - 1,05	13 - 15

(1) Ideal for washing crockery and cutlery of breakfast and dinner (**fresh soil**).
Characterised by a short duration.
This is the perfect daily programme, made to meet the needs of a family of 4 persons who only wish to load breakfast and dinner crockery and cutlery.

(2) Testing programme for EN 50242 (see "Hints for Test Centres). This programme, developed for the use of detergents with enzymes, allows you to achieve, with reduced consumption of energy the same cleaning results that would otherwise be obtained only with the 65°C programmes and conventional detergents. To compensate the lower temperature, the duration of washing and drying have been extended.

(3) The consumption values are intended as a guide and depends on the pressure and the temperature of the water and also by the variations of the power supply.

"AUTOMATIC" washing programme

During the "AUTOMATIC" washing programme the amount of soil on the dishes is determined by how cloudy the water is.
If the appliance is partially loaded and the dishes lightly soiled, the "prewash", "main wash", and "rinse" phases of the programme are shorter and the water consumption level is lower.

If the appliance is fully loaded and the dishes heavily soiled, the "prewash"", main wash", and "rinse" phases of the programme are longer and the water consumption level is higher.

For this reason the programme duration, water and energy consumption levels can vary within the stated range for AUTOMATIC programme (see "Washing programmes chart").

During the "AUTOMATIC" programme the temperature of the main wash water is also automatically adjusted between 50°C and 65°C depending on the amount of soil on the dishes.

152958 39/0en 16-02-2005 10:50 Pagina 28

Starting a washing programme

In this fully integrated appliance the controls are located on the top of the door. When selecting a programme, the door needs to be slightly open.

1. Check that the baskets have been loaded correctly and that the spray arms can rotate freely

2. Turn on the water tap

3. Press the On/Off button

All the indicator lights of the programme selection buttons illuminate.

4. Setting and starting the programme

a) To select a programme, press the programme button of the desired washing programme (see "Washing programmes" chart).

The corresponding indicator light remains illuminated while the other programme buttons indicator lights turn off.
In the digital display flashes the running time (in minutes) of the selected programme

b) To select the delay start of the programme, press the "delay start" button until the number of the hours selected for the delay start, followed by the letter **h**, will appear in the digital display (e.g. **1h**).

The start of the programme or of the countdown for the delay start will occur only after the closure of the door, until that moment you can modify the selection made.

Close the dishwasher door.

a) If delay start has not been set, the programme will start automatically.

b) If delay start has been set, the countdown starts automatically and will decrease with steps of 1 hours.

The opening of the door will not modify or interrupt the countdown. Once the delay start has elapsed the programme will start automatically.

152958 39/0en 16-02-2005 10:50 Pagina 29

Once the washing programme has started, a point-shaped optical signal appears on the floor beneath the dishwasher's door.
This optical signal will remain illuminated for all the duration of the washing programme.
If the appliance has been installed higher up with a furniture door mounted flush, the optical signal will be no longer visible.

5. To interrupt or cancel a washing programme in progress

Interrupt, or cancel a washing programme in progress ONLY if it's absolutely necessary

Attention! Hot steam may escape when the door is opened.
Open the door carefully.

To interrupt a washing programme in progress
Open the dishwasher door; the programme will stop.
Close the door; the programme will start from the point at which it was interrupted.

To cancel a washing programme in progress

Open the dishwasher door.
Press simultaneously the function buttons **2** and **3** for about 2 seconds, the indicator light of the button corresponding to the running programme starts flashing for about 2 seconds.

After about 2 seconds the indicator lights of all the programme buttons will illuminate indicating that the running programme has been cancelled and that the machine has returned to setting mode.

It is now possible to select and start a new washing programme. (If a new washing programme will be selected, check that there is detergent in the detergent dispenser).

6. To cancel a delay start in progress

Open the dishwasher door and follow the same instructions as for "To cancel a washing programme in progress".

With the cancelling of the delay start also the set programme has been cancelled.

Set the washing programme again.

152958 39/0en 16-02-2005 10:50 Pagina 30

7. End of the washing programme

The dishwasher will automatically stop and an audible signal informs you of the end of the washing programme.

When the washing programme has ended, the optical signal on the floor beneath the dishwasher's door will turn off. Open the dishwasher door only when this optical signal turns off.

Open the door carefully.

In the digital display appears **0** (remaining programme time), **only** in this case the programme has ended.

Switch off the dishwasher by pressing the On/Off button.

Open the door and wait a few minutes before removing the dishes; in this way they will be cooler and the drying will be improved.

8. Unloading the dishwasher

Hot dishes are sensitive to knocks. The dishes should therefore be allowed to cool down before removing from the appliance.

Empty the lower basket first and then the upper one; this will avoid water dripping from the upper basket onto the dishes in the lower one.

Water may appear on the sides and the door of the dishwasher as the stainless steel will eventually become cooler then the dishes.

⚠ **When the washing programme has finished, it is recommended that the dishwasher is unplugged and the water tap turned off.**

152958 39/0en 16-02-2005 10:50 Pagina 31

Maintenance and cleaning

Clean the external surfaces of the machine and control panel with a damp soft cloth. If necessary use only neutral detergents. Never use abrasive products, scouring pads or solvent (acetone, trichloroethylene etc....).

Ensure that the seals around the door, the detergent and rinse aid dispensers are cleaned regularly with a damp cloth.

We recommend every 3 months to run a 65°C wash programme without dishes using detergent.

Cleaning the filters

The filters must be checked and cleaned from time to time.
Dirty filters will degrade the washing result.

1. Open the door, remove the lower basket.

2. The dishwasher filter system comprises a coarse filter (**A**), a microfilter (**B**) and a flat filter (**C**).
Unlock the filter system using the handle on the microfilter, and remove.



3. Turn the handle about 1/4 a turn anticlockwise and remove.



4. Take hold of the coarse filter (**A**) by the handle with the hole and remove from the microfilter (**B**).

5. Clean all filters thoroughly under running water.

6. Remove the flat filter (**C**) from the base of the washing compartment and clean both faces thoroughly.



7. Put the flat filter (**C**) back in the base of the washing compartment.

8. Place the coarse filter (**A**) in the microfilter (**B**) and press together.

9. Put the filter combination in place and lock by turning the handle clockwise to the stop. During this process ensure that the flat filter does not protrude above the base of the washing compartment.

Attention!

Under no circumstances may the dishwasher be used without filters. Incorrect repositioning and fitting of the filters will produce poor washing results.

NEVER try to remove the upper spray arm.

If residues of soil have clogged the holes in the upper spray arm, remove them with a toothpick.



152958 39/0en 16-02-2005 10:50 Pagina 33

Prolonged periods of non-operation

If you are not using the machine for any period of time you are advised to:

1. Unplug the appliance and then turn off the water.

2. Leave the door ajar to prevent the formation of any unpleasant smells.

3. Leave the inside of the machine clean.

Frost precautions

Avoid placing the machine in a location where the temperature is below 0°C. If this is unavoidable, empty the machine, close the appliance door, disconnect the water inlet pipe and empty it.

Moving the machine

If you have to move the machine (moving house etc....):

1. Unplug it.

2. Turn the water tap off.

3. Remove the water inlet and discharge hoses.

4. Pull the machine out together with the hoses.

Avoid over tilting the machine during transportation.

152958 39/0en 16-02-2005 10:50 Pagina 34

What to do, when...

Certain problems are due to the lack of simple maintenance or oversights, which can be solved with the help of the instructions given here, without calling out an engineer.

...a flashing fault code appears

The dishwasher will not start or stops during operation.
The intervention of an alarm is indicated by a sequence of intermittent audible signals.
The point-shaped optical signal on the floor beneath the dishwasher's door is flashing (not visible if the appliance has been installed higher up with a furniture door mounted flush).

Open the dishwasher door, in the digital display is visible a fault code (see following chart).
Carry out the following suggested corrective actions.

Fault code / Malfunction	Possible cause	Solutions
in the digital display appears F10 The machine does not fill with water	**The water tap is blocked or furred with limescale.**	**Clean the water tap.**
	The water tap is turned off.	**Turn the water tap on.**
	The filter (where present) in the threaded hose fitting at the water inlet valve is blocked.	**Clean the filter in the threaded hose fitting.**
	The water inlet hose has not been correctly laid or it is bent or squashed.	**Check the water inlet hose connection.**
in the digital display appears F20 The dishwasher will not drain	**The sink spigot is blocked.**	**Clean out the sink spigot.**
	The water drain hose has not been correctly laid or it is bent or squashed.	**Check the water drain hose connection.**
in the digital display appears F30	**Anti-flood device has activated.**	**Close the water tap and contact your local Service Force Centre.**

152958 39/0en 16-02-2005 10:50 Pagina 35

Once the checks have been carried out, to continue the programme press the button of the programme that was running before the intervention of the alarm and close the door. The programme will continue from the point at which it was interrupted. If the fault code reappears contact your local Service Force Centre.

For other combinations of fault codes not described in the above chart will appear, please contact your local Service Force Centre.

...there are problems when operating the dishwasher

Fault	Possible cause	Solutions
The programme does not start	**The dishwasher door has not been properly closed.**	**Close the door.**
	The main plug is not plugged in.	**Insert the mains plug.**
	The fuse has blown in the household fuse box.	**Replace the fuse.**
	For dishwasher models with delay start option: Delay start has been selected.	**If dishes are o be washed immediately, cancel the delay start.**
There is a whistling noise during washing	**The whistling is not a cause for concern.**	**Use a different brand of detergent.**

152958 39/0en 16-02-2005 10:50 Pagina 36

...the wash results are not satisfactory

The dishes are not clean

- The wrong washing programme has been selected.
- The dishes were arranged in such a way as to stop water reaching all parts of the surface. The baskets must not be overloaded.
- The spray arms do not rotate freely due to wrong arrangement of the load.
- The filters in the base of the washing compartment are dirty or incorrectly positioned.
- Too little or no detergent has been used.
- Where there are limescale deposits on the dishes; the salt container is empty or the wrong level of the water softener has been selected.
- The drain hose connection is not correct.
- The salt container cap is not properly closed.

The dishes are wet and dull

- Rinse aid was not used.
- The rinse aid dispenser is empty.

There are streaks, milky spots or a bluish coating on glasses and dishes

- Decrease rinse aid dosing.

Water drops have dried onto glasses and dishes

- Increase rinse aid dosing.
- The detergent may be the cause. Contact the detergent manufacturer's consumer care line.

152958 39/0en 16-02-2005 10:50 Pagina 37

Service

If after all these checks, the problem persists, contact your local Service Force Centre, quoting the model (Mod.), product number (PNC) and serial number (S.N.).

This information can be found on the rating plate located on the side of the dishwasher door (see picture).

So that you always have these numbers at hand, we recommend you to make a note of them here:

Mod. : . . . . . .

PNC : . . . . . .

S.N. : . . . . . .



Service and spare parts

This product should be serviced by an authorised service engineer, and only genuine spare parts should be used.
Under no circumstances should you attempt to repair the machine yourself.
Repairs carried out by inexperienced persons may cause injury or serious malfunctioning. Contact your local Service Force Centre.
Always insist on genuine spare parts.

152958 39/0en 16-02-2005 10:50 Pagina 38

Guarantee terms (Belgium)

Our appliances are produced with the greatest of care. However, a defect may still occur. Our consumer services department will repair this upon request, either during or after the guarantee period. The service life of the appliance will not, however, be reduced as a result.

This declaration of guarantee terms is based on European Union Directive 99/44/EC and the provisions of the Civil Code. The statutory rights that the consumer has under this legislation are not affected by this declaration of guarantee terms.

This declaration does not affect the vendor's statutory warranty to the end user. The appliance is guaranteed within the context of and in adherence with the following terms:

1. In accordance with provisions laid down in paragraphs 2 to 15, we will remedy free of charge any defect that occurs within 24 months from the date the appliance is delivered to the first end user.
These guarantee terms do not apply in the event of use for professional or equivalent purposes.

2. Performing the guarantee means that the appliance is returned to the condition it was in before the defect occurred. Defective parts are replaced or repaired.
Parts replaced free of charge become our property.

3. So as to avoid more severe damage, the defect must be brought to our attention immediately.

4. Applying the guarantee is subject to the consumer providing proof of purchase showing the purchase and/or delivery date.

5. The guarantee will not apply if damage caused to delicate parts, such as glass (vitreous ceramic), synthetic materials and rubber, is the result of inappropriate use.

6. The guarantee cannot be called on for minor faults that do not affect the value or the overall reliability of the appliance.

7. The statutory warranty does not apply when defects are caused by:
- a chemical or electrochemical reaction caused by water,
- abnormal environmental conditions in general,
- unsuitable operating conditions,
- contact with harsh substances.

8. The guarantee does not apply to defects due to transport which have occurred outside of our responsibility. Nor will the guarantee cover those caused by inadequate installation or assembly, lack of maintenance or failure to respect the assembly instructions or directions for use.

9. Defects that result from repairs or measures carried out by people who are not qualified or expert or defects that result from the addition of non-original accessories or spare parts are not covered by the guarantee.

152958 39/0en 16-02-2005 10:50 Pagina 39

10. Appliances that are easy to transport may be delivered or sent to the consumer services department. Home repairs are only anticipated for bulky appliances or built-in appliances.

11. If the appliances are built-in, built-under, fixed or suspended in such a way that removing and replacing them in the place where they are fitted takes more than half an hour, the costs that result therefrom will be charged for. Connected damage caused by these removal and replacement operations will be the responsibility of the user.

12. If, during the guarantee period, repairing the same defect repeatedly is not conclusive, or if the repair costs are considered disproportionate, in agreement with the consumer, the defective appliance may be replaced with another appliance of the same value.
In this event, we reserve the right to ask for a financial contribution calculated according to the length of time it has been used.

13. A repair under guarantee does not mean that the normal guarantee period will be extended nor that a new guarantee period begins.

14. We give a twelve month guarantee for repairs, limited to the same defect.

15. Except in the event where liability is legally imposed, this declaration of guarantee terms excludes any compensation for damage outside the appliance for which the consumer wishes to assert his rights. In the event of legally admitted liability, compensation will not exceed the purchase price paid for the appliance.

These guarantee terms are only valid for appliances purchased and used in Belgium. For exported appliances, the user must first make sure that they satisfy the technical conditions (e.g.: voltage, frequency, installation instructions, type of gas, etc.) for the country concerned and that they can withstand the local climatic and environmental conditions. For appliances purchased abroad, the user must first ensure that they meet the qualifications required in Belgium. Non-essential or requested adjustments are not covered by the guarantee and are not possible in all cases.

Our consumer services department is always at your disposal, even after the guarantee period has expired.

152958 39/0en 16-02-2005 10:50 Pagina 40

Address for our consumer services department:

Electrolux Home Products Belgium
ELECTROLUX SERVICE
Bergensesteenweg, 719
1502 Lembeek

Consumer services

Telephone
02/363.04.44

Telefax
02/363.04.00
02/363.04.60

consumer.services@electrolux.be
repairs.belgium@electrolux.be

152958 39/0en 16-02-2005 10:50 Pagina 41

Technical specifications

Dimensions:	Width Height Max depth Max depth with open door	59.6 cm 86.8 - 94.8 cm 55.5 cm 119 cm
Electrical connection: Voltage Overall power Fuse	Information on the electrical connection is given on the rating plate on the inner edge of the dishwasher's door.	
Water supply pressure:	Minimum Maximum	50 kPa (0.5 bar) 800 kPa (8 bar)
Capacity:		12 place settings

CE This appliance complies with the following E.E.C. Directives:

- 73/23 or 19.2.73 (Low Voltage Directive) and subsequent modifications;
- 89/336 or 3.5.89 (Electromagnetic Compatibility Directive) and subsequent modifications.

152958 39/0en 16-02-2005 10:50 Pagina 42

Installation instructions

Any electrical and/or plumbing work required to install this appliance should be carried out by a qualified electrician and/or plumber or competent person.

Remove all packaging before positioning the machine.

If possible, position the machine next to a water tap and a drain.

Building-in

This dishwasher is designed to be fitted under a kitchen counter or worksurface.

Attention!
Carefully follow the instructions on the enclosed template for building in the dishwasher and fitting the furniture panel.

No further openings for the venting of the dishwasher are required, but only to let the water fill and drain hose and power supply cable pass through.

The dishwasher incorporates adjustable feet to allow the adjustment of the height.

During all operations that involve accessibility to internal components the dishwasher has to be unplugged.

When inserting the machine, ensure that the water inlet hose, the drain hose and the supply cable are not kinked or squashed.

Levelling

Good levelling is essential for correct closure and sealing of the door.

When the appliance is correctly levelled, the door will not catch on either side of the cabinet.

If the door does not close correctly, loosen or tighten the adjustable feet until the machine is perfectly level.

Fixing to the adjacent units

The dishwasher must be secured against tilting.

Therefore make sure that the counter it is fixed under, is suitably secured to a fixed structure (adjacent kitchen units cabinets, wall).

152958 39/0en 16-02-2005 10:50 Pagina 43

Water supply connections

This dishwasher may be fed with either hot (max. 60°) or cold water. Nevertheless we advise you a cold water supply.
A hot water supply is not always efficient with very soiled crockery as it shortens the washing programmes a lot.

For making the connection itself, the coupling nut fitted to the machine's supply hose is designed to screw onto either a 3/4" inch gas thread spout or to a purpose made quick-coupling tap such as the Press-block.

The water pressure must be within the limits given in the "Technical specifications". Your local Water Authority will advise you on the average mains pressure in your area.

The water inlet hose must not be kinked, crushed, or entangled when it is being connected up.

The dishwasher features fill and drain hoses which can be turned either to the left or the right to suit the installation by means of the locknut. **The locknut must be correctly fitted to avoid water leaks.** (**Attention! NOT** all models of dishwashers have fill and drain hoses provided with locknut. In this case, this kind of facility is not possible).

If the machine is connected to new pipes or pipes which have not been used for a long time, you should run the water for a few minutes before connecting the inlet hose.

⚠ **Do not use, for connection, old hoses which have been used in another appliance.**

The dishwasher is fitted with safety devices that prevent the wash water returning into the drinking water system and comply with the applicable plumbing regulations.

152958 39/0en 16-02-2005 10:50 Pagina 44

Water inlet hose with safety valve

After connecting the double-walled water inlet hose, the safety valve is next to the tap. Therefore the water inlet hose is only under pressure while the water is running. If the water inlet hose starts to leak during this operation, the safety valve cuts off the running water.

Please take care when installing the water inlet hose:

- The electrical cable for the safety valve is in the double-walled water inlet hose. Do not immerse the water inlet hose or the safety valve in water.
- If water inlet hose or the safety valve is damaged, remove the mains plug immediately.
- A water inlet hose with safety valve must only be replaced by a specialist or by the consumer services department.
- Place the water inlet hose in such a way that it is never higher than the bottom edge of the safety valve.

152958 39/0en 16-02-2005 10:50 Pagina 45

Water outlet hose connection

The end of the drain hose can be connected in the following ways:

1. To the sink outlet spigot, securing it to the underside of the work surface. This will prevent waste water from the sink running into the machine.

2. Hooked over the edge of the sink using the special curved plastic guide (if provided with the machine).

3. To a stand pipe provided with vent-hole, minimum internal diameter 4 cm.

The waste connection must be at a height of between 30 cm (minimum) and 100 cm (maximum) from the bottom of the dishwasher.

The drain hose can face either to the right or left of the dishwasher

Ensure the hose is not bent or squashed as this could prevent or slow down the discharge of water.

The sink plug must not be in place when the machine is draining as this could cause the water to syphon back into the machine.

If you use a drain hose extension it must be no longer than 2 metres and its internal diameter must be no smaller than the diameter of the hose provided.



Likewise the internal diameter of the couplings used for connections to the waste outlet must be no smaller than the diameter of the hose provided.

Attention!
Our appliances are supplied with a security device to protect against the return of dirty water back into the machine.
If the spigot of your sink has a "no return valve" incorporated this can prevent the correct draining of your dishwasher.
We advise you therefore to remove it.

152958 39/0en 16-02-2005 10:50 Pagina 46

Electrical connection

Information concerning the electrical connection is given on the rating plate on the edge of the dishwasher's door.

Before plugging the appliance into the wall socket, make sure that:

1. The mains voltage and current rating at the site of installation match the nominal voltage and current rating given on the rating plate.
2. The meter, fuses, mains power supply and wall socket can all take the maximum load required. Make sure that the socket and plug are compatible without having to use any type of adaptor. If necessary, have the domestic wiring system socket replaced.

To isolate the dishwasher from mains, remove the mains plug.

Important!
The plug must still be accessible after the appliance has been installed.

In case that the electrical cable has to be replaced, please contact your local consumer services department.

The appliance should not be connected to the electrical supply by means of an extension cable.

Safety standards require the appliance to be earthed.
The manufacture accepts no liability for failure to observe the above safety precautions.

152958 39/0en 16-02-2005 10:50 Pagina 47

Hints for test centres

Testing in accordance with **EN 60704** must be carried out with appliance fully loaded and using the test programme (see "Washing programmes" chart).

Test in accordance with **EN 50242** must be carried out when the salt dispenser and rinse aid container have been filled with salt and rinse aid respectively and using the test programme (see "Washing programmes" chart).

Load:	12 standard place settings
Rinse aid setting	Position 4 (type III)
Detergent dosage:	5 g + 25 g (type B)



Arrangement upper basket
(take off the glass holder)



Arrangement lower basket



Arrangement knife basket



Cup racks: position A

Arrangement cutlery
basket

From the Electrolux Group. *The world's No.1 choice.*

The Electrolux Group is the world's largest producer of powered appliances for kitchen, cleaning and outdoor use. More than 55 million Electrolux Group products (such as refrigerators, cookers, vacuum cleaners, chain saws and lawn mowers) are sold each year to a value of approx. 14 billion USD in more than 150 countries around the world.

AEG Hausgeräte GmbH
Postfach 1036
D-90327 Nürnberg

http://www.aeg.hausgeraete.de

© Copyright by AEG

152 958 39/0 Subject to change without notice 02/05